

## Audi A6L Service lamp Reset & Service Interval Set

### Service Lamp Reset procedure:

- (1) Connect X-431, select [CAN BUS II DIAGNOSTIC CONNECTOR] connector;
- (2) Ignition ON;
- (3) Select **Audi maker**;
- (4) Select **CAN bus** system;
- (5) Access *17 Instrument cluster*;
- (6) Select *10 Adaptation*, enter 02 channel, click **OK**;
- (7) Click “-” button to change the adaptation value into “0”, click OK;
- (8) Exit to end the reset.

### Set Interval procedure:

- (1) Connect X-431, select [CAN BUS II DIAGNOSTIC CONNECTOR] connector;
- (2) Ignition ON;
- (3) Select **Audi maker**;
- (4) Select **CAN bus** system;
- (5) Access *17 Instrument cluster*;
- (6) Select *10 Adaptation*, enter 40 channel, click **OK**;
- (7) Select “->” to enter the mileage interval for next service (e.g.: input 100 for 5000km,  $100 = (15000 - 5000) / 100$ ), click OK;
- (8) Exit to end the set.

Note: Before change the interval mileage, please verify that the adaptation value in each channel Number: Channel “41” is “0”, channel “42” is “150”, channel “43” is “150” and channel “44” is “365”, otherwise, please modify it as above procedure.