

Adjustment of high idle speed for Jetta 2V vehicle

(2004-3-11)

The engine idle speed of Jetta 2V vehicle will become too high after the throttle is cleaned. Use the following methods to adjust the idle speed:

1. Connect X431
2. Turn ON the ignition switch (do not start engine)
3. Enter the "engine electronics" system to read fault memory and erase fault memory.
4. Select the function "Basic setting" and enter the channel No.

098: Santana, Jetta 5V

060: Jetta 2V, Passat

001: Audi 200, Red Flag 488, B4

5. Click [OK] button to see the data displayed in section 4. Exit the function when X431 prompts that ECU adaptation is normal (successful).

6. Select the function [Adaptation]
7. Enter "000" and click [OK] button
8. Clear the memory value