

SSANGYONG DIAGNOSTIC FUNCTION LIST V13.00 (UPDATE : 2006-8-18)

vehicle	system	sub system	function
01. CHAIRMAN	01. ENGINE CONTROL	01. 3.2 BOSCH	1. read dtc 2. clear dtc 3. data stream
		02. 3.2 VDO	
		03. 2.8 VDO	
		04. 2.3 VDO	
	02. AUTOMATIC TRANSAXLE	01. BTRA	1. read dtc 2. clear dtc
		02. NGA	
	03. ANTI-LOCK BRAKE SYSTEM	01. ABS/ABS 5.3	1. read dtc 2. clear dtc 3. data stream 4. actuation
		02. ABS/ABD 5.3	
		03. ABS/ASR 5.3	
		04. TEVES(ABS/ESP)	
05. TEVES(ABS)			
04. SRS-AIRBAG	01. BOSCH	1. read dtc 2. clear dtc	
	02. SRE-NCS	1. read dtc 2. clear dtc 3.version info	
05. ELEC. CONTROL SUSPENSION		1. read dtc 2. clear dtc 3. data stream	
02. REXTON	01. ENGINE CON. (GASOLINE)	01. 3.2 VDO	1. read dtc 2. clear dtc 3. data stream
		02. 2.8 VDO	
		03. 2.3 VDO	
		04. DSL D27DT	
	02. AUTOMATIC TRANSAXLE	01. GASOLINE	1. read dtc 2. clear dtc 3. data stream
		02. DC 5 AT(T-Tronic)	1. read dtc 2. clear dtc 3. data stream 4.version info
	03. ANTI-LOCK BRAKE SYSTEM	01. BOSCH	1. read dtc 2. clear dtc 3. data stream 4. actuation
		02. TEVES(ABS/ESP)	
		03. TEVES(ABS)	
	04. SRS-AIRBAG	01. SRE-6	1. read dtc 2. clear dtc 3.version info
02. SRE-NCS			
05. FOUR WHEEL DRIVE SYSTEM			
03. MUSSO	01. ENGINE CON. (GASOLINE)	01. 3.2 MSE	1. read dtc 2. clear dtc 3. data stream
		02. 2.3 MSE	
	02. AUTOMATIC TRANSAXLE	01. 20PIN CONNECTOR	
		02. 16PIN CONNECTOR	
	03. ANTI-LOCK BRAKE SYSTEM	01. ABS 5.0	1. read dtc 2. clear dtc 3. data stream 4. actuation
		02. ABS/ABD 5.0	
		03. ABS/EBD 5.3	
		04. ABD/EBD 5.3	
	04. FOUR WHEEL DIRVE SYSTEM		1. read dtc 2. clear dtc
	05. ELEC. CONTROL SUSPENSION		1. read dtc 2. clear dtc 3. data stream 4.actuation 5.version info
04. KORANDO	02. AUTOMATIC TRANSAXLE	01. 20PIN CONNECTOR	1. read dtc 2. clear dtc 3. data stream
		02. 16PIN CONNECTOR	
	03. ANTI-LOCK BRAKE SYSTEM	01. ABS 5.0	1. read dtc 2. clear dtc 3. data stream 4. actuation
		02. ABS/ABD 5.0	
		03. ABS/EBD 5.3	
04. ABD/EBD 5.3			
04. FOUR WHEEL DIRVE SYSTEM		1. read dtc 2. clear dtc	
05. ELEC. CONTROL SUSPENSION		1. read dtc 2. clear dtc 3. data stream 4.actuation 5.version info	
05. ISTANA	01. ANTI-LOCK BRAKE SYSTEM		1. read dtc 2. clear dtc 3. data stream 4. actuation
06. RODIUS	01. ENGINE CONTROL(DIESEL)		1. read dtc 2. clear dtc 3. data stream 4.actuation 5.version info
	02. AUTOMATIC TRANSAXLE		1. read dtc 2. clear dtc 3. data stream 4.version info
		03. ANTI-LOCK BRAKE SYSTEM	
	04. SRS-AIRBAG	01. TEVES(ABS/ESP)	1. read dtc 2. clear dtc 3. data stream 4. actuation
		02. TEVES(ABS)	
05. FOUR WHEEL DRIVE SYSTEM	01. NEW PART TIME(16PIN)	1. read dtc 2. clear dtc 3. data stream 4.version info	
	02. NEW TOD		
07. KYRON	01. ENGINE CONTROL(DIESEL)		1. read dtc 2. clear dtc 3. data stream 4.actuation 5.version info
	02. AUTOMATIC TRANSAXLE		1. read dtc 2. clear dtc 3. data stream 4.version info
		03. ANTI-LOCK BRAKE SYSTEM	
	04. SRS-AIRBAG	01. TEVES(ABS/ESP)	1. read dtc 2. clear dtc 3. data stream 4. actuation
		02. TEVES(ABS)	
05. FOUR WHEEL DRIVE SYSTEM	01. SRE-NCS	1. read dtc 2. clear dtc 3.version info	
	02. NEW TOD		